




Please follow the steps below to update the drivers on your new Linksys WUSB6300 V2:

- 1) Insert the Linksys Wireless Adapter into your PC
- 2) Locate the device in your Device Manager under 'Other devices'



- 3) Right click on the device and select "Update driver"
- 4) Choose "Browse my computer for drivers"



How do you want to search for drivers?

→ Search automatically for drivers

Windows will search your computer for the best available driver and install it on your device.

→ Browse my computer for drivers


Locate and install a driver manually.

Cancel


2261 Keating Cross Rd, Victoria, British Columbia, Canada V8M 2A5
Tel: +1 250-656-0771 Toll Free: +1 800-663-8721 Fax: +1 250-655-3655
Email: sales@AMLoceanographic.com
www.AMLoceanographic.com



- 5) Navigate to the WiFi Adapter Drivers Folder located on the AML supplied USB stick. If this folder is not on your USB stick, please contact service@amloceanographic.com for assistance. Please note, your file path may differ slightly but the folder you are looking for should be called “WiFi Adapter Drivers”.



- 6) Select this folder and the drivers should successfully install. The image below represents what you should see.



- 7) Restart your computer

2261 Keating Cross Rd, Victoria, British Columbia, Canada V8M 2A5
Tel: +1 250-656-0771 Toll Free: +1 800-663-8721 Fax: +1 250-655-3655
Email: sales@AMLoceanographic.com
www.AMLoceanographic.com