


Hemisphere GNSS AtlasLink/A101/A222/A325/A631 Wiring



J4 - Port A Terminal Block
1 - RS232 TX – violet
2 - RS232 RX – pink
3 - Signal ground – yellow

J3 – Power Terminal Block
Rd - +V – red
Bk - 0V – black

J2 - Port B Terminal Block
1 - RS232 TX – brown
2 - RS232 RX – blue
3 - PPS(+) – gray

J1 CAN Terminal Block
CAN_H – orange
CAN_L – tan